

CornerStone ANSI 107 Class 3 Soft Shell Jacket

Size Chart

	S	M	L	XL	2XL	3XL	4XL	5XL
Chest	35-37	38-40	41-43	44-46	47-49	50-53	54-57	58-60

CHEST WIDTH

Measure under the arm and around the fullest part of the chest with arms down, keeping tape horizontal.